

MODEL: HDR-CX240, HDR-CX330, HDR-CX405, HDR-CX440, HDR-PJ275, HDR-PJ340, HDR-PJ350, HDR-PJ440, HDR-PJ540, HDR-PJ670, HDR-PJ810.**No.** E58409844**Subject:** Information for AC adaptor (USB AC charger) concentration**Date:** Jan. 23. 2017.**Symptom:**

Replacement adaptor for AC adaptor (USB AC charger) is arranged.

Applicable S/N:

All

Solution:

When exchanging AC adaptor (USB AC charger) on the original side of the following table, please exchange it by AC-UUD12.

Original		Substitute		
Model No.	Plug type	Model No.	P/N	Plug type
AC-UD11 AC-UUD11	Direct plug	AC-UUD12	1-493-085-11	Direct plug

REQUIRED PART / TOOL / SOFTWARE

Plug type	Model No.	P/N	Destination
Direct plug	AC-UUD12	1-493-085-11	USA, Canada, Mexico, Japan, Taiwan